

Q. How do I know if I need the system software upgrade?

A. "You will need to upgrade if your VRD-MC10 has one of the following system software versions.

5.08.70.86

5.09.84.01

5.09.84.06

5.09.85.08

To check the system software version please follow the following steps.

- Turn VRD-MC10 on
- Press ""Return"" to go to the main menu
- From the main menu, select ""Setup"" / ""System Info""

Q. Which brands and models can I record AVCHD video footages, other than Sony Handycam®?

A. Please refer to a list of the compatible camcorders. Link to <http://sony.storagesupport.com/product/334#documents>

Q. How can I upgrade the firmware of my VRD-MC10?

A. Please download the new firmware from DVDirect support web site. Link to <http://sony.storagesupport.com/product/334#drivers>

Q. Can I create "AVCHD" discs from DSC (Digital Still Camera)?

A. No. VRD-MC10 does not support AVCHD disc creation from any DSCs.

Q. Can I create "AVCHD Lite" discs from DSC (Digital Still Camera) other than Sony Cyber-Shot?

A. You can create AVCHD discs only from Sony Cyber-Shot..

Q. Can I record AVCHD captured footage with a recording mode of [HD FX] (for Handycam®) to DVD?

A. No. You cannot record AVCHD captured footage with a bit rate exceeding 18Mbps, such as [HD FX] (for Handycam®) to DVD media in accordance with AVCHD regulations.

Q. Message "XX/YY videos are not recordable. Continue copying?" appears on LCD display.

A. HD (High Definition) video taken in REC mode at a bit rate exceeding 18Mbps, such as in [HD FX] mode (i.e. High Definition Handycam®) cannot be recorded. Recording such video to DVD media does not comply with AVCHD format regulation. Select [Yes] to record other than the above condition videos. (XX/YY: number of unrecordable videos/total number of videos)

Q. What is "Disc Index" playback function?

A. "VRD-MC10 plays the first 10 seconds of each AVCHD video footage so that you can preview the content of each video footage. To enjoy ""Disc Index"" playback function, please press [Disc Index] button appeared on DVD menu.

If you playback an AVCHD disc on VRD-MC10, you can also play the whole footage by pressing ""Play"" button on either VRD-MC10 or the supplied remote commander."

Q. Can I use "Disc Index" playback function with BD player?

A. "Yes. You can use ""Disc Index"" playback function with BD recorders, BD players, PlayStation3 as well as VRD-MC10. To enjoy ""Disc Index"" playback function, please press [Disc Index] button appeared on DVD menu.

If you playback an AVCHD disc on VRD-MC10, you can also play the whole footage just pressing ""Play"" button on either VRD-MC10 or the supplied remote commander. "

Q. How many songs (tracks) can VRD-MC10 store as the original BGM (Back Ground Music) for photo slideshow from an audio CD?

A. VRD-MC10 can store only one music track up to 10 minutes. When a new track is recorded, the prior track is automatically erased..

Q. Can I transfer videos recorded to Secure Digital (SD), or SDHC media card by Handycam® to DVD?

A. "Yes. You will need to upgrade your system software if the current system software version is one of the followings:

5.08.70.86

5.09.84.01

5.09.84.06

5.09.85.08

To check the system software version please follow the following steps.

- Turn VRD-MC10 on
- Press "Return" to go to the main menu
- From the main menu, select "Setup"/ "System Info"