



VRD-MC10 System Software Update Instructions

Update the system software of your VRD-MC10 with the system software update file “ **rox5185.svf** ” previously downloaded. Refer to the following procedure.

Preparation

For updating the system software on the VRD-MC10, you need to use a memory card. Save the system software update file onto the top directory of the memory card. (Alternatively, use a blank CD-R/RW disc. When using a CD-R/RW disc, save the system software update file onto the top directory of the CD-R/RW disc using CD creation function on your computer.)

Notes

When the system software is updated, previous settings are reset and the recording history necessary for copying only new video/photo is cleared.

Updating the System Software

1. Turn on the VRD-MC10.
2. Press **[RETURN]** button to display **Setup** screen.




3. Insert the memory card with the update file into the VRD-MC10.

Note When using a CD-R/RW disc with the update file, do not insert the disc into the VRD-MC10 yet.

4. Press [↑] / [↓] repeatedly to select “**System Info**”, and press [ENTER] button.


When using a memory card for update


The following screen displays. Go to step 6.




When using a CD-R/RW disc for update

The following screen displays. Go to step 5.




*  in the display indicates the version of the system software currently installed in VRD-MC10.

5. **When using a CD-R/RW disc for update** Insert the CD-RW disc with the update file into the VRD-MC10. The following screen displays. Go to step 6.



* in the display indicates the version of the system software currently installed in VRD-MC10.



6. Select "OK" and press **[ENTER]** button. The following screen displays.




* in the display indicates the version of the system software to be installed.

7. Select "OK" and press **[ENTER]** button. Updating starts. (It will take about 30 seconds to complete updating.)

Note: Never unplug the power cable while updating.

8. When updating is complete, press  (power) button. Remove the memory card from the VRD-MC10 and press  (power) button again to restart the VRD-MC10.

Note: When using a CD-R/RW disc for updating, the disc tray will open automatically when updating is complete. Remove the disc and press  (power) button.

Confirming the revision number of the system software

Turn on the VRD-MC10 and press **[RETURN]** button to display **Setup** screen. Select **“System Info”** and press **[ENTER]** button to display **System Info** screen. Make sure that **“5.10.06.28”** is displayed as below.

